

CEIA OPENGATE Stretch Sleeves - Installation

1

Carefully stretch the bottom of the sleeve over the top of the CEIA OPENGATE.

You may hear a few of the hem stitches popping, this is normal. Work the bottom of the sleeve over the top until it is fully on.



2

Rotate the handle opening to align with the handle before you put the entire sleeve on. Carefully move the sleeve down toward the handle.

It may be easiest to have someone hold the sleeve above the pillar as another person scrunches it down.



3

Put the entire sleeve on before attempting to stretch it over the handle and down to the bottom.

For easier installation, make sure the bottom of the sleeve is fully gathered just above the handle.



4

A little at a time, stretch the sleeve over the handle, it will be normal to hear some popping.

Do not attempt to stretch the bottom over the handle all at once. Use your thumbs to give you some leverage as you move the sleeve over the handle until the handle sits in the opening.



5

Smooth out the sleeve from top to bottom until it looks presentable.



6

Please note that the top of the sleeve should NOT go to the top of the pillar. CEIA requires the sleeve to sit just below the CEIA branding badge as shown.

